Optical transmitter OTF302 DTT processing units MCA101L, MCA101T and wideband LNB LWB201L, LWB202L

System description

The optical transmitter OTF302 is intended to distribute SAT IF and DTT, FM, DAB signals through a fibre optic. Transmitted SAT IF signal 290-2350 MHz is collected from wideband LNB LWB201L / LWB202L. DTT, FM, DAB signals are collected from DTT processing units MCA101L / MCA101T.

Application diagram



Figure 1. Transmitting system

The system is not flexible to use components of other manufacturers with similar functionality. The tramsmitting system is compatible with ORF302, ORD301F, ORQ302 and etc. optical receivers. See www.terraelectronics.com.

Manual in .pdf



EN

Safety instructions

Installation of the products must be done according IEC60728-11 and national safety standards. The products are powered from 10 - 20 V DC. This voltage is not dangerous to life.

Any repairs must be done by a skilled personnel.

To ensure safe operation of the products follow these instructions:

Do not supply power until all cables have been connected correctly.

The products should be mounted with connectors underneath to avoid the water ingress inside.

Safety of laser product

Optical transmitter module contains laser diode sources. These devices are rated under IEC60825-1: "Safety of Laser Products", Part 1: Equipment classification and requirements as CLASS 1M laser product. When operating the equipment note the following:



Most fiber optic laser wavelengths are totally invisible to the eye and will cause permanent eye damage. Never look into the end of a fiber on a powered device through a magnifying device (microscope, eye loupe, magnifying glass, etc.). Before using such devices always double check that power is disconnected or, if possible, completely disconnect the unit from any power source.

To verify the light output always use an instrument, such as an optical power meter. Operate only with the proper optical fiber installed in the device optical connector. Whenever the optical connector is empty the laser transmitter should be turned off. Before applying power always connect a fiber to the output of the device. Never leave equipment with radiating bare fibers accessible - always cap the connectors.

This product complies with the relevant clauses of the European Directive 2002/96/EC. The unit must be recycled or discarded according to applicable local and national regulations.

Equipment intended for indoor usage only.

Functional grounding. Connect to the main potential equalization.



This product is in accordance with Custom Union Technical Regulations: "Electromagnetic compatibility of technical equipment" CU TR 020/2011, "On safety of low-voltage equipment" CU TR 004/2011.



The product has integrated LTE filter.

This product is in accordance with safety standard AS/NZS 60065: 2012 and EMC standards of Australia.

Optical transmitter OTF302

Product description

The optical transmitter OTF302 is intended to convert wideband SAT IF and DTT, FM, DAB to optical signals for future distribution through a fibre optic.

The transmitter is compatible with ORF302, ORD301F, ORQ302 and etc. optical receivers.

External view of OTF302



Figure 2. External view of the transmitter

- 1. OPTICAL OUT optical output connector.
- 2. DC IN +20 V DC powering input and communication port with PC102W. F socket.
- 3. V, DC 13 V SAT IF vertical polarization input, 13 V 150 mA DC output. F socket.
- 4. H, DC IN/OUT- SAT IF horizontal polarization input, DC input/output. F socket.
- 5. DTT, DC OUT DTT input from MCA101x, DC output. F socket.
- 6. Functional grounding clamp
- 7. SAT input level and laser status indicator:

```
red – to high
```

```
green – correct (AGC range)
```

yellow - to low

Blinking any color - laser aging or failure.

8. DTT input level and DTT DC output status indicator:

```
red - to high
```

```
green – correct (AGC range)
```

```
yellow – to low
```

Blinking any color - DTT DC output overload.

REQUIREMENTS FOR EXTERNAL POWER SUPPLY UNIT (PSU)

- · Output voltage
- Output current

• Ripple at single and/or double mains frequency < 10 mV p-p

• Ripple & noise

Short circuit protection

• Double insulated (marked 🔲)

• Meet EN 55022 class B conducted emisions requirements, measuring with grounded load

Optical connections

<u>Note</u>: All optical connectors and adaptors should be cleaned before connecting them. If optical reception power of the receiver decrease, fiber connection should be cleaned and maintained. Fiber connectors should never be left uncovered.

1. Align the FC/UPC connector key-way (type R) with the receptable key-way.



2. Push firmly to locate the key-ways and then rotate the coupling ring.



3. Do not exceed the minimum bending radius of fibers: must be not less 30 mm when connecting optic cable to the system.

Installation instructions

Read the safety instruction first.

The unit is dedicated for indoor installation and shall not be exposed to dripping or splashing water.

For outdoor installation use appropriate box. We recommend to put this box in shadow of the SAT dish to protect from direct sun radiation.

The laser is highly sensitive to overheating.

< 200 mV p-p

recommended to use PSU with 50% extra power reserve

20 V

Technical specifications

Туре	OTF302	
Wideband inputs		
Frequency range	2 x (290-2350) MHz	
RF input level (AGC range) for 60 transponders	70-90 dBμV (per carrier)	
LNB remote feeding	13 V via V input - 150 mA max, 20 V via H input, 250 mA max. total	
DTT input		
System frequency range**	87.5-240 / 470-790 MHz	
RF input level***	83 dBµV / 83-93 dBµV (per carrier)	
Remote feeding	19 V 150 mA max.	
Optical output****		
General		
Input return loss / impedance	> 12 dB / 75 Ω	
Supply voltage	20 V	
Power consumption*	4 W max.	
Operating temperature range	-20° C ÷ + 40° C	
Dimensions/Weight (packed)	116x84x25.5 mm/0.28 kg	

* without remote feeding

** the set with MCA101x

*** FM level the same like DTT, DAB level 12 dB below

**** Туре	Power	Laser	Wavelenght	Connector IN
OTF302 3C55 E	3 dBm min	DFB	1550 nm ±3 nm	FC/UPC
OTF302 6F31 E	6 dBm	FP	1310 nm	FC/UPC
OTF302 6F55 E	6 dBm	FP	1550 nm	FC/UPC

Remotely monitored parameters by PC102W:

- DC voltages on V,H and DTT inputs
- internal temperature
- laser status
- V polarity input RF power per channel (average)
- DTT input UHF RF power per channel (average)

Parameters of connected MCA101x:

- supply voltage
- internal temperature
- UHF input RF power per channel (average)
- number of UHF channels

When the MCA101x rotary switch is set to position "0", the number of DTT channels in the UHF band can be set remotely.

See www.terraelectronics.com.

DTT processing units MCA101T, MCA101L

Product description

Masthead DTT processing units MCA101L, MCA101T are intended for operation with optical transmitter OTF302. The units are converting UHF DTT channels and through pass FM and DAB signals.

Built-in LTE 700/800 suppression filter |

The units can be used in outdoor conditions as well.

External view of MCA101L, MCA101T





- 1. UHF DTT input
- 2. VHF FM, DAB/DTT input
- 3. RF OUT / DC IN RF output / +10...+20 V DC powering input
- 4. UHF DTT channels number setting rotary switch
- 5. FM, DAB level regulator
- 6. screwdriver

Figure 3. External view of the units

INSTALLATION INSTRUCTIONS

Read the safety instruction first.

For outdoor installation.

The length of the cable between MCA101x and OTF302 must be less then 20 m of RG6U type.

Set the number of DTT channels in UHF band with rotary switch (pos. 4, Figure 3) before fitting unit on mounting place. Good equalization of UHF DTT channels improve system performance. Set using regulator 5 (see Figure 3) DAB and FM signals level on OTF302 input precisely.

NOTE: The number of DTT channels in the UHF band can be set remotely (rotary switch position "0"). Details see in OTF302 and PC102W user manuals www.terraelectronics.com.

Technical characteristics

Туре		MCA101T	MCA101L		
RF inputs		·			
VHF gain / input level	87.5-240 MHz	-314 dB adjustable, passive			
		min. 86 dBµV, max. 97 dBµV**			
UHF input level	470-694 MHz	55-80 dBµV* 🗋	-		
	470-790 MHz	-	55-80 dBµV* 🗋		
UHF noise figure		< 5 dB			
UHF AGC range		25 dB			
RF output					
Output level UHF, AGC range, 8 DTT channels		93 dBµV			
General					
Return loss / impedance		> 10 dB / 75 Ω			
Supply voltage		10 - 20 V			
Current consumption		130 mA max.			
Operating temperature range		-20° ÷ +50° C			
Dimensions/Weight (packed)		89x107x432 mm/0.18 kg			

* AGC range

** see requirements for OTF302 DTT input

The units have communication channel with optical transmiter OTF302 for parameters monitoring by PC102W programmer.

Remotely monitored parameters are:

- supply voltage
- internal temperature
- UHF input RF power per channel (average)

- number of UHF channels set by rotary switch if it is not in position "0". If rotary switch is in position "0", it is seen value, remotely set by PC102W and it is possible to change it.

See www.terraelectronics.com.

Wideband LNB LWB201L, LWB202L

Product description

Wideband 40 mm low noise down converter units LWB201L, LWB202L are dedicated for operation with OTF302 optical transmitter.

External view of LWB201L, LWB202L



1. V - SAT IF V polarization output, DC input

2. H - SAT IF H polarization output, DC input

Figure 4. External view of the wideband LNB

INSTALLATION INSTRUCTIONS

Read the safety instruction first.

For outdoor installation.

The length of the cable between LWB201L, LWB202L and OTF302 must be less then 10 m of RG6U type. We recommend to use relatively bigger dishes for ensure better MER value of the transmitted signals.

Technical characteristics

Туре	LWB201L	LWB202L	
Input frequency range	10.7 - 12.75 GHz		
Noise figure	0.7 dB typical, 1.0 dB max.		
LO frequency	10.4 GHz	10.41 GHz	
LO initial accuracy	± 500 kHz		
LO temperature drift	± 250 kHz		
LO phase noise	< - 75 dBc/Hz @ 10 kHz		
Conversion gain, typical	55 dB		
Gain variation full band	4 dB max.		
Gain variation over 27 MHz	± 0.5 dB		
Image rejection	40 dB min		
Cross-pol isolation, typical	22 dB		
Output impedance/return loss	75 Ω / 12 dB		
Output frequency range	300-2350 MHz	290-2340 MHz	
General			
Supply voltage	10 - 20 V		
Current consumption	20 V 0.1 A		
Power consumption	2 W max.		
Operating temperature range	-30° C ÷ + 60° C		
Dimensions/Weight (packed)	141x89x63 mm / 0.35 kg		

TERRA